


Root Feeder



HD-8™ Surface Root Feeder

Description

Part No.

Complete Surface Feeder Unit

Style 1 Surface Feeder with splash Shield

39919

Style 3 Surface Feeder with cup style shield

39920

Maintenance Parts for HD-8 SURFACE ROOT FEEDER

Dwg.
Ref.

No. Description

Part No.

1. Gun Adaptor	39914
2. Surface Root Feeder Body, 36"	39910
3. Collar 1-1/2	39906
4. Grip Handle	39907

Dwg.
Ref.

No. Description

Part No.

5. JD-9C High Pressure Spray Gun	Not included
6. Plug Cap	39911
7. Retainer Splash Shield	39905
8. Spring Retainer Bottom	39904
9. Spring Retainer Top	39903
10. O-Ring to seal adapter	39912
11. Set Screw	39908
12. Splash Shield	39900
13* Surface Feeder Cup Style Shield	39913
14. Compression Spring, 9"	39901
15. Tip and Shaft	39902
16. Compression Fitting Complete	39909
17. Check Valve 3PSI Brass	39916
18. Aluminum Inner Tube	39915

*Item 13 can replace item 12 as an option

HUDSON®

H. D. HUDSON MANUFACTURING COMPANY

500 North Michigan Avenue

Chicago, IL 60611-3769

©HDH Mfg. Co. All rights reserved

Phone: 1-800-745-2392 Fax: 1-312-644-7989
pro@hdhudson.com www.hdhudson.com